Integrator
On/Off TTL
Power
(+- 15V)
Fast
Error Out
Fast
Error In
Current
Feed-
Forward
Current
Out
Error
In
Piezo
Out
Ramp
(In/Out)*
Piezo
Feed-
Forward
To change servo gain and invert current/piezo out see switches and pots
on the circuit board
*Based on internal jumpers
Ramp ground 100 Ohms to circuit ground

Monitors
Piezo
Error
Integrator
Current
Error
Monitor
ground 100 Ohms to circuit ground
Current
Gain
Piezo
Gain
Piezo Bias
Error Offset
Piezo Ramp
Gain
More
Integrator Fault
Reset Switch
On
Off
On
Off
On
Off
Fast Error
Current Error
Piezo
Error
Piezo
Ramp
Integrator
Fault
Current
Piezo
Ramp
Fast
15V
-15V
Laser Lock
v1.1

Integrator
On/Off TTL
Power
(+- 15V)
Fast
Error Out
Fast
Error In
Current
Feed-
Forward
Current
Out
Error
In
Piezo
Out
Ramp
(In/Out)*
Piezo
Feed-
Forward
To change servo gain and invert current/piezo out see switches and pots
on the circuit board
*Based on internal jumpers
Ramp ground 100 Ohms to circuit ground

Monitors
Piezo
Error
Integrator
Current
Error
Monitor
ground 100 Ohms to circuit ground
Current
Gain
Piezo
Gain
Piezo Bias
Error Offset
Piezo Ramp
Gain
More
Integrator Fault
Reset Switch
On
Off
On
Off
On
Off
Fast Error
Current Error
Piezo
Error
Piezo
Ramp
Integrator
Fault
Current
Piezo
Ramp
Fast
15V
-15V
Laser Lock
v1.1